## Ex 16 – Forced Landing Without Power

AIM: TO LAND SAFELY WITH PARTIAL OR COMPLETE ENGINE FAILURE

THREATS: TERRAIN, ELECTRICITY PYLONS, MILITARY AIRCRAFT

ERRORS: BREACHING 500' RULE, TOO SLOW / STALL

Field:

Shape

Surface

Slope

Surround

Size

MANAGEMENT: 500' RULE, GOOD LOOKOUT, LIGHTS ON, WATCH SPEED

